

电加热锅炉 Electrically Heated Boiler ST-01A



<p>4A103006 DZ47-60 C20</p>  <p>断路器 400V~ 6000A 50Hz</p>	<p>6Q1063</p>  <p>温控探头</p>	<p>4A112021</p>  <p>电脑板</p>
<p>2K130011 L=170</p>  <p>探针</p>	<p>4J103025</p>  <p>探针护套</p>	<p>2J101009 JYYL-5</p>  <p>压力控制器 0.4Mpa G1/8 16A/220VAC</p>
<p>2N114002 JKY-2-1/8</p>  <p>汽管接头</p>	<p>2K106008 G1/8 14×24</p>  <p>压力控制器接头</p>	<p>2K117015 JYAQ-5L</p>  <p>安全阀 0.7Mpa G1/8</p>

<p>4B109008 KCD6</p>	<p>4K104253</p>	
 <p>船型开关 6A 250V AC</p>	 <p>压力表 0.6bar Φ40</p>	 <p>排污总成</p>
<p>4F2030021 DP003D1</p>	<p>2K105004</p>	<p>4A101011 CJX2-2501</p>
 <p>水泵 OPEN FLOW: 3.5L/min VOLTS: 220VAC AMPS: 0.6A MAX WORKING: 100PSI</p>	 <p>3X2补芯</p>	 <p>交流接触器 220V 50Hz</p>
<p>2D104001</p>		
 <p>1.5寸M8万向轮</p>	 <p>炉胆及安装板</p>	 <p>顶盖</p>

	<p>2K136030</p>	<p>2K108016</p>
 <p>Φ6×1压力控制器铜管</p>	 <p>3分出气阀</p>	 <p>3×2铜弯头带3分并帽</p>
<p>2K1370032</p>	<p>2K135008</p>	<p>2K135011</p>
 <p>不锈钢抱箍 Φ8, Φ9.5, 14-16mm, 13-19mm</p>	 <p>4分插10外螺纹易接头</p>	 <p>2分插10内螺纹易接头</p>
<p>0103010673231</p>	<p>2K1080065</p>	<p>0103010673252</p>
 <p>2分蒸汽胶管 L=170</p>	 <p>2分外螺弯头</p>	 <p>2分蒸汽胶管 L=240</p>

2K118010	2K135010	4B109006 KCD2
 <p>4分内外螺球阀</p>	 <p>铜三通易接头</p>	 <p>船型开关 16A 125VAC 16 (4) A 250VAC T85</p>
	2K135007	2N115009 YL-06
 <p>排污管及排污管罩 2K13605 2D106033</p>	 <p>4分插10内螺纹易接头</p>	 <p>进水电磁阀 (两位三通) 口径Φ3, AC220V, G1/4</p>
0103050271 0103050272	4H10101200 R1097盛田	4A106001 RT18-32
 <p>进水过滤器</p>	 <p>电热管 220V 4KW</p>	 <p>断路器底座 500V~ 32A</p>

4B109006 RT28-32	01030312062	4J104004
 <p>保险丝 500V~100kA 2A</p>	 <p>塑料拉手</p>	 <p>护线圈 Φ10</p>
4J104008	2K115007	2K110005
 <p>护线圈 Φ18</p>	 <p>4分三通</p>	 <p>4分镀锌内接</p>
2K109002	6Q1083	2K111001
 <p>4分内外螺弯头</p>	 <p>4分内外螺止回阀</p>	 <p>2分铜内接</p>

2K108018



4分×2分弯头

2K135021



2分插8内螺纹易接头
